




Forward run



Reverse run



Forward run



Reverse run

Caution : When 110v transfer to 220v , only

3 wires were connected , Z_1 , U_1 , V_2

not Z_2 ,

Fig.14 The motor 110v/220v Transferring Connection
Diagram For 1 Phase