

# RADIATOR

< REMOVAL AND INSTALLATION >


[V9X]

## REMOVAL AND INSTALLATION

### RADIATOR

#### Exploded View

INFOID:000000006467154



- |                               |                            |                             |
|-------------------------------|----------------------------|-----------------------------|
| 1. Fan shroud (Lower)         | 2. Fan shroud (Upper)      | 3. Turbocharger water hose  |
| 4. Mounting rubber (lower)    | 5. Mounting rubber (Upper) | 6. Radiator                 |
| 7. Radiator cap               | 8. Mounting rubber (Upper) | 9. Radiator hose (lower)    |
| 10. Reservoir tank hose       | 11. Reservoir tank hose    | 12. Reservoir tank hose     |
| 13. A/T fluid cooler hose     | 14. A/T fluid cooler hose  | 15. Reservoir tank hose     |
| 16. Reservoir tank hose       | 17. Radiator hose (Upper)  | 18. Drain plug              |
| 19. O-ring                    |                            |                             |
| A. To EGR water pump          | B. To water inlet          | C. To A/T fluid cooler tube |
| D. To turbocharger water pump | E. To A/T fluid cooler     | F. To water outlet          |
| G. To water outlet            | H. To water outlet         |                             |

Refer to [Gl-9. "Component"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000006467155

#### REMOVAL

CO-70